














# DISCOVER OUR ENGINE PARTS



	TYPE	EXPLANATION	PRODUCTS IN STOCK
	<b>Belts &amp; PTO parts</b>	Belts power several components in the engine, such as the water pump, fan, alternator, etc. Power Take-Off parts transfer some of the engine's power to drive an external application.	1.900+
	<b>Cylinder heads</b>	Mounts on top of the Engine block to form the combustion chambers.	900+
	<b>Camshafts &amp; valve train</b>	The valve train, which includes the camshaft, is the assembly of parts making up the mechanical system that controls the operation of intake and exhaust valves.	1.300+
	<b>Engine timing</b>	Timing parts synchronise the rotation of the crankshaft and the camshaft. In diesel engines, they also synchronise the injection pump.	500+
	<b>Engine blocks</b>	This main component houses the cylinders, the crank mechanism and the coolant and oil passages.	250+
	<b>Crank mechanism</b>	Converts the back and forth movement of the pistons in the cylinders to a rotating movement.	4.000+
	<b>Lubrication system</b>	Distributes oil to all moving parts of the engine to reduce friction and minimise wear and tear.	1.000+
	<b>Engine electricals</b>	Various electrical components that help the engine run like it should, or stop the engine when required.	800+
	<b>Overhaul kits &amp; gaskets</b>	Gaskets are used in various parts of the engine to keep debris from entering the engine, maintain consistent internal pressure, and keep oil and other fluids inside. An overhaul kit contains all the wearing and assembly parts needed to overhaul an engine.	8.000+
	<b>Air intake &amp; exhaust system</b>	Ensures even distribution of air between the different cylinders, and releases exhaust fumes from the engine.	2.800+
	<b>Fuel system</b>	Stores and supplies fuel, mixing it with the right amount of air, and moving it into the engine to produce power.	2.500+
	<b>Ignition system</b>	Petrol and LPG engines require a spark to initiate the combustion process. This spark comes from the ignition system and ignites the fuel-air mixture.	1.000+

[Click here to find your engine parts in our webshop](#)



**TVH PARTS NV**

Brabantstraat 15 • 8790 Waregem • Belgium

T +32 56 43 42 11 • F +32 56 43 44 88 • [info@tvh.com](mailto:info@tvh.com) • [www.tvh.com](http://www.tvh.com)

**KEEPS YOU GOING.**